



OCKAM




Matryx Display Quick Reference Guide

Matryx Display Quick Reference Guide


Add A Page



Modify A Page




Delete A Page






Matryx Display Quick Reference Guide

Add Stopwatch Page




Add Trip Log Page





Matryx Display Quick Reference Guide

Set Averaging (Dampening)




Note:
Damping pages always start with the default number, not the current value.


OCKAM

Matrixx Display Quick Reference Guide

Add A Stripchart Page



Set Calibrations



OCKAM

26 Higgins Dr.
Milford, CT 06460
P 203 877 7453
F 203 878 0572
www.ockam.com
lat@ockam.com